


UVO | Power to **Connect**

UVO Smartwatch Application Quick Reference Guide



The Power to Surprise

Content

1. Introduction to UVO Smartwatch Application

2. Application Features

UVO | Power to
Connect



1. Introduction to UVO Smartwatch Application

There are two smartwatch applications available for UVO customers

I. UVO Smartwatch App (For remote vehicle services)

Kia UVO Smartwatch Application:

With the UVO smartwatch application you can remotely control your vehicle and gain access to your vehicle status. It can be accessed through below applications:



Wear OS
(Android)



Watch App
(iOS)



Wear OS
(Android)



II. UVO Watch Face App (Dedicated watch face design)

Kia UVO Watch Face Application*:

UVO watch face application is a personalised watch face design specially for Kia customers. It can be accessed through below applications:



Wear OS
(Android)



Wear OS
(Android)

Shortcut to UVO smartwatch app

Double tap anywhere on screen
to change watch dial colour
(6 colour options available)



* Not available on iOS platform

2. Application features



Tap to open UVO smartwatch app

Day, date and time indicator

Foot steps indicator

Smartwatch battery indicator

Double tap anywhere on watch screen to change dial colour

Colour changing dial elements (Double tap on watch screen)



2. Application features

UVO smartwatch home screen:



Tap UVO to open application




Flash screen



Check for automatic login in UVO mobile app*



Watch app homescreen**



Scroll down to access app features



Option 2: Watch face not available

Alternatively tap on app icon in main menu screen of the app (in case watch face not available (iOS)/ watch face app is not downloaded)

*In case customer has logged out of UVO mobile application, smartwatch will fail to connect

**Remote engine Start and Stop is not available in case vehicle transmission is Manual

2. Application features


Remote Engine Start:



Tap on **engine start**



Enter 4 digit security pin set on the UVO mobile app



Command is sent to vehicle
Note: Climate settings and remote engine start duration is as per setting done in UVO mobile app



Command success/ failure notification

Remote Engine Stop:



Tap on **engine stop**



Enter 4 digit security pin set on the UVO mobile app




Command sent to vehicle



Command success/ failure notification

2. Application features

Remote Door Lock:



Tap on Door Lock



Enter 4 digit security pin set on the UVO mobile app




Command sent to vehicle



Command success/failure notification

Remote Door Unlock:



Tap on Door unlock



Enter 4 digit security pin set on the UVO mobile app




Command sent to vehicle



Command success/failure notification

2. Application features

Horn & Light:



Tap on Horn and Lights

Enter 4 digit security pin set on the UVO mobile app

Command sent to vehicle

Command success/failure notification

Smart Pure Air:



Start vehicle engine


Engine start successful

Select smart pure air from home screen

Check air quality inside car

2. Application features


Vehicle Status:



Tap on vehicle status on home screen



App gets latest vehicle status



Vehicle status screen

Refresh icon to get latest status update



Scroll down to see status of vehicle

